



RSD-1-RTU-1-CW-SS RSD-1-RTU-1-CW-CE

REPLACEMENT PARTS


doc no RSD-RTUX24037 / Feb 9, 2024




0111-302
14" DEEP
0111-295
ROLLER ASSEMBLY



0111-303
18" FLAT PAN
0111-295
ROLLER ASSEMBLY



0111-553
MULTI-STEP PAN
10"-16"
0111-295
ROLLER ASSEMBLY




0111-532
MULTI-STEP PAN
6"-14"
0111-295
ROLLER ASSEMBLY




RSD-DT-125
DRIVE HUB

RSD-LLA-537
NOZZLE INSERT WITH SHORT TMSLOCK



EA-MOT-105-156
TURNTABLE MOTOR




RSD-DS-101
NOZZLE O-RING


RSD-DLA-21C33
SMALL NOZZLE ASSY




RSD-DLA-607
PRIMING NOZZLE



EP-PS-1
48VDC POWER SUPPLY




EA-ASM-10-156
ALL-IN-ONE CONTROL BOARD




RSD-NP-200-P
RTU PUMP COMPLETE

EA-SEN-05-156
HOME SENSOR




RSD-DS-111
NOZZLE CLEANING ASSEMBLY




PM-FT-24
22.6 OETIKER CLAMP


RSD-NP-100-DT



EA-ASM-02A-156
KEYPAD ASSEMBLY
STANDARD, LARGE PCB



0111-462
LENS ASSEMBLY



0111-277

RSD-SV-523

0111-287

RSD-SV-560

0111-278-2


CD-SA-14

0505-620
19.8 OETIKER CLAMP


RSD-DTV-107



0111-280
SAUCE INLET STRAINER
COMPLETE



RSD-DTV-108



EP-CORD-3
110V POWER CORD

Wunder-Bar™

AUTOMATIC BAR CONTROLS, INC.
2060 CESSNA DR, SUITE 100
VACAVILLE, CA 95688

www.wunderbar.com

TOLL FREE : (800) 722-6738
PHONE: (707) 448-5151
FAX : (707) 448-1521